Malware Lab4

Chen Zhuge IVCM132116

(This report was regenerated based on historical materials on 16 June, 2020.)

My work is largely based on the scripts on http://hooked-on-mnemonics.blogspot.com/2011/12/yara-md5.html. I changed the original scripts a bit to suit the lab's requirement.

Based on the MD5 scanning, the malwares could still be found if their names were changed intentionally. The following logs prove that Yara can still find ff11.exe , after its name was changed to ChangedName.txt .

chen:yaratest\$ python yaraMD5.py

Yara MD5 match. Malware original name: FILE_ff11_exe . Malware current name: ff11.exe

Yara MD5 match. Malware original name: FILE kl3090 exe . Malware current name: kl0309.exe

chen:yaratest\$ python yaraMD5.py

Yara MD5 match. Malware original name: FILE ff11 exe . Malware current name: ChangeName.txt

Yara MD5 match. Malware original name: FILE_kl3090_exe . Malware current name: kl0309.exe

Appendix:

Before changing the file name:

After changing the file name:

```
chen:lab3$ python yaraMD5.py
please input your studentcode(132116):132116
Currently processing .D5_Store
Currently processing changed.pdf
Yara MD5 match. Malware original name: FILE_ff11_exe . Malware current name: changed.pdf
Currently processing delta_865123.exe
Currently processing delta_exel_78655.zip
Currently processing delta_exel_78655.zip
Currently processing discounts.exe
Currently processing document.exe
Currently processing dropped.exe
Currently processing ed950167765
Currently processing ef50167765
Currently processing fft.exe
Currently processing infected.pdf
Currently processing installAntivirus2010.exe
Currently processing InstallAntivirus2010.exe
Currently processing is exex
Currently processing is exex
Currently processing is exex
Currently processing kit.exe
Currently processing Lab3Document.txt
Currently processing md5_b.yara
Currentlab3$
```

```
import hashlib
import sys
import yara
from StringIO import StringIO
from os import listdir
def MD5(d):
        05(d):
d = buffer of the read file
This function hashes the buffer
source: http://stackoverflow.com/q/5853830
     if type(d) is str:
    d = StringIO(d)
md5 = hashlib.md5()
     while True:

data = d.read(128)

if not data:
     break
md5.update(data)
return md5.hexdigest()
def yaraScan(d, n, st):
     # d = buffer of the read file
# Scans SWF using Yara
# test if yara module is installed
# if not Yara can be downloaded from http://code.google.com/p/yara-project/
if st != 132116:
          print "Warning: Studentcode doesn't match. Yara will run but result will not be as expected."
     try:
    imp.find_module('yara')
    import yara
except ImportError:
    print '\t[ERROR] Yara module not installed - aborting scan'
           return
      except:
           pass
print '\t[ERROR] Yara compile error - aborting scan'
     m = r.match(data=d)
      for X in m:
           r = yara.compile(r'md5_b.yara', externals={"var1":st})
     except:
            print '\t[ERROR] Yara compile error - aborting scan'
           return
     m = r.match(data=d)
     for X in m:
    print '\tYara MD5 match. Malware original name:', X, '. Malware current name:', n
     studentcode=input("please input your studentcode(132116):")
for each_file in listdir("/Users/chen/study/currentcourses/Malware2/lab3"):
                f = open(each_file)
                na = each_file
print "Currently processing", na
           except Exception:
    print '[ERROR] File can not be opended/accessed'
           yaraScan(MD5(f), na, studentcode)
if __name__ == '__main__':
    main()
```